

Cleaning advise

digital printed wallcovering

2020

general

- Stains should always be removed as quickly as possible.
- Soak up any wet stains with an absorbent material.
- When cleaning always work from the edge of the stain to the centre in order to contain the stain.
- The general cleaning of digital printed wallcovering should be done with mild soap and warm water.

cleaning advise

- Remove superficial dry dirt with a soft brush.
- Rub the area carefully with a cloth or sponge that contains a detergent solution or Vescom Cleaner. Clean from bottom of wall upward. Before attempting, evaluate how it affects the wallcovering by trying this in an inconspicuous spot on the wallcovering.
- Then rinse thoroughly with clean water from the top down using a sponge.
- Dry the wallcovering with a soft lint free cloth or towel.
- Examine the area and repeat the cleaning procedure if necessary.
- Repeated use of stronger cleaners in the same area of the wallcovering can cause the wallcovering to lose its homogeneous surface appearance.
- Time is especially important for removing materials containing colors or solvents such as ballpoint ink, markers, paint, and some foodstuffs.
- Excess soiling materials, such as chewing gum, crayon, paint, or tar like substances should be carefully scraped off prior to the other cleaning attempts.
- Do not use steel wool or powdered abrasive because they can damage the image and textured surface.
- Never touch printed and digitally printed wallcovering with (pure)alcohol. The print will fade or disappear.

Vescom will not be held responsible for any damage that may be caused during the cleaning process.